



turn to the experts™ 

LUV INVERTER SERIES

Service Manual



42/38LUVH025N-1
42/38LUVH035N-1
42/38LUVH045N-1
42/38LUVH055N-1
42/38LUVH065N-1
42/38LUVH075N-1

CONTENTS

PART1. Safety Precaution

PART2. Outline and Dimensions

PART3. Refrigerant Cycle Diagram

PART4. Wiring Diagram

PART5. Installation Details

PART6. Operation Description

PART7. Trouble Shooting

PART8. Capacity Table

PART1. Precaution

1. Safety Precaution

- To prevent injury to the user or other people and property damage, the following instructions must be followed.
- Incorrect operation due to ignoring instruction will cause harm or damage.
- Before service the unit, be sure to read this service manual at first.

2. Warning

➤ Installation

- Do not use a defective or underrated circuit breaker. Use this appliance on a dedicated circuit.

There is risk of fire or electric shock.

- For electrical work, contact the dealer, seller, a qualified electrician, or an authorized service center.

Do not disassemble or repair the product, there is risk of fire or electric shock.

- Always ground the product.

There is risk of fire or electric shock.

- Install the panel and the cover of control box securely.

There is risk of fire or electric shock.

- Always install a dedicated circuit and breaker.

Improper wiring or installation may cause fire or electric shock.

- Use the correctly rated breaker or fuse.

There is risk of fire or electric shock.

- Do not modify or extend the power cable.

There is risk of fire or electric shock.

- Do not install, remove, or reinstall the unit by yourself (customer).

There is risk of fire, electric shock, explosion, or injury.

- Be caution when unpacking and installing the product.

Sharp edges could cause injury, be especially careful of the case edges and the fins on the condenser and evaporator.

- For installation, always contact the dealer or an authorized service center.
- Do not install the product on a defective installation stand.
- Be sure the installation area does not deteriorate with age.

If the base collapses, the air conditioner could fall with it, causing property damage, product failure, and personal injury.

- Do not let the air conditioner run for a long time when the humidity is very high and a door or a window is left open.
- Take care to ensure that power cable could not be pulled out or damaged during operation.

There is risk of fire or electric shock.

- Do not place anything on the power cable.

There is risk of fire or electric shock.

- Do not plug or unplug the power supply plug during operation.

There is risk of fire or electric shock.

- Do not touch (operation) the product with wet hands.

- Do not place a heater or other appliance near the power cable.

There is risk of fire and electric shock.

- Do not allow water to run into electrical parts.

It may cause fire, failure of the product, or electric shock.

- Do not store or use flammable gas or combustible near the product.

There is risk of fire or failure of product.

- Do not use the product in a tightly closed space for a long time.

Oxygen deficiency could occur.

- When flammable gas leaks, turn off the gas and open a window for ventilation before turn the product on.

- If strange sounds or smoke comes from product, turn the breaker off or disconnect the power supply cable.

There is risk of electric shock or fire.

- Stop operation and close the window in storm or hurricane. If possible, remove the product from the window before the hurricane arrives.

There is risk of property damage, failure of product, or electric shock.

- **Do not open the inlet grill of the product during operation. (Do not touch the electrostatic filter, if the unit is so equipped.)**

There is risk of physical injury, electric shock, or product failure.

- **When the product is soaked, contact an authorized service center.**

There is risk of fire or electric shock.

- **Be caution that water could not enter the product.**

There is risk of fire, electric shock, or product damage.

- **Ventilate the product from time to time when operating it together with a stove etc.**

There is risk of fire or electric shock.

- **Turn the main power off when cleaning or maintaining the product.**

There is risk of electric shock.

- **When the product is not be used for a long time, disconnect the power supply plug or turn off the breaker.**

There is risk of product damage or failure, or unintended operation.

- **Take care to ensure that nobody could step on or fall onto the outdoor unit.**

This could result in personal injury and product damage.

➤ CAUTION

- **Always check for gas (refrigerant) leakage after installation or repair of product.**

Low refrigerant levels may cause failure of product.

- **Install the drain hose to ensure that water is drained away properly.**

A bad connection may cause water leakage.

- **Keep level even when installing the product.**

It can avoid vibration of water leakage.

- **Do not install the product where the noise or hot air from the outdoor unit could damage the neighborhoods.**

It may cause a problem for your neighbors.

- **Use two or more people to lift and transport the product.**

- **Do not install the product where it will be exposed to sea wind (salt spray) directly.**

It may cause corrosion on the product. Corrosion, particularly on the condenser and evaporator fins, could cause product malfunction or inefficient operation.

➤ Operational

- **Do not expose the skin directly to cool air for long time. (Do not sit in the draft).**
- **Do not use the product for special purposes, such as preserving foods, works of art etc.**

It is a consumer air conditioner, not a precision refrigerant system.

There is risk of damage or loss of property.

- **Do not block the inlet or outlet of air flow.**
- **Use a soft cloth to clean. Do not use harsh detergents, solvents, etc.**

There is risk of fire, electric shock, or damage to the plastic parts of the product.

- **Do not touch the metal parts of the product when removing the air filter. They are very sharp.**
- **Do not step on or put anything on the product. (outdoor units)**
- **Always insert the filter securely. Clean the filter every two weeks or more often if necessary.**

A dirty filter reduces the efficiency of the air conditioner and could cause product malfunction or damage.

- **Do not insert hands or other objects through air inlet or outlet while the product is operated.**
- **Do not drink the water drained from the product.**
- **Use a firm stool or ladder when cleaning or maintaining the product.**

Be careful and avoid personal injury.


- **Replace the all batteries in the remote control with new ones of the same type. Do not mix old and new batteries or different types of batteries.**

There is risk of fire or explosion.

- **Do not recharge or disassemble the batteries. Do not dispose of batteries in a fire.**
- **If the liquid from the batteries gets onto your skin or clothes, wash it well with clean water. Do not use the remote of the batteries have leaked.**


PART2. Outline and Dimensions

1. Indoor Unit




Model	W	D	H
42LUVH025N-1	790	195	265
42LUVH035N-1	920	225	292
42LUVH045N-1	920	225	292
42LUVH055N-1	1080	230	330
42LUVH065N-1			
42LUVH075N-1	1250	230	325

2. Outdoor Unit



Model	L1	W1	H	L2	W2
38LUVH025N-1	760	285	590	530	290
38LUVH035N-1	760	285	590	530	290
38LUVH045N-1	845	320	700	560	335
38LUVH065N-1	900	315	860	590	333
38LUVH075N-1					


PART3. Refrigerant Cycle Diagram




PART4. Wiring Diagram

1. Indoor Unit


42LUVH025N-1




42LUVH035N-1



42LUVH045N-1




42LUVH055N-1, 42LUVH065N-1



PART4, 2


INDOOR WIRING DIAGRAM

202033190160






2. Outdoor Unit

38LUVH025N-1, 38LUVH035N-1



38LUVH045N-1





PART5. Installation Details

1. Wrench torque sheet for installation

Outside diameter		Torque	Additional tightening torque
mm	inch	N.cm	N.cm
Φ6.35	1/4	1500(153kgf.cm)	1600(163kgf.cm)
Φ9.52	3/8	2500(255kgf.cm)	2600(265kgf.cm)
Φ12.7	1/2	3500(357kgf.cm)	3600(367kgf.cm)
Φ16	5/8	4500(459kgf.cm)	4700(479kgf.cm)
Φ19	3/4	6500(663kgf.cm)	6700(683kgf.cm)

2. Connecting the cables

The power cord of connect should be selected according to the following specifications sheet.


Rated current of appliance	Nominal cross-sectional area (mm ²)
>3 and ≤6	0.75
>6 and ≤10	1
>10 and ≤16	1.5
>16 and ≤25	2.5

The cable size and the current of the fuse or switch are determined by the maximum current indicated on the nameplate which located on the side panel of the unit. Please refer to the nameplate before selecting the cable, fuse and switch.

3. Pipe length and the elevation

The pipe length and refrigerant amount:

Model	Pipe size		Standard length (m)	Max. Elevation B (m)	Max. Length A (m)	Additional refrigerant (g/m)
	Gas	Liquid				
42/38LUVH025N-1	3/8" (Φ9.53)	1/4" (Φ6.35)	5	8	20	20
42/38LUVH035N-1 42/38LUVH045N-1	1/2" (Φ12.7)	1/4" (Φ6.35)	5	8	20	20
42/38LUVH055N-1 42/38LUVH065N-1 42/38LUVH075N-1	5/8" (Φ16.0)	3/8" (Φ9.53)	5	10	25	40



Caution:

The capacity test is based on the standard length and the maximum permissive length is based on the system reliability.

The oil trap should be installed per 5-7 meter


4. Air purging with vacuum pump

Air and moisture in the refrigerant system have undesirable effects as below:

- Pressure in the system rises.
- Operating current rises.
- Cooling or heating efficiency drops.
- Moisture in the refrigerant circuit may freeze and block capillary tubing.
- Water may lead to corrosion of parts in the refrigerant system.

Therefore, the indoor units and the pipes between indoor and outdoor units must be leak tested and evacuated to remove gas and moisture from the system.

Air purging with vacuum pump



Procedure

- 1) Completely tighten the flare nuts of the indoor and outdoor units, connect the manifold valve charge.
- 2) Connect the charge hose connection to the vacuum pump.
- 3) Fully open the handle Lo of the manifold valve.
- 4) Operate the vacuum pump to evacuate. After starting evacuation, slightly loose the flare nut of the Lo valve on the gas pipe side and check the air is entering. (Operation noise of the vacuum pump changes and a compound meter indicates 0 instead of minutes)
- 5) After the evacuation is complete, fully close the handle Lo valve of the manifold valve and stop the

operation of the vacuum pump. Make evacuation for 15 minutes or more and check the compound meter indicates -76cmHg.

- 6) Turn the stem of the Hi valve about 45°counterclockwise for 6 or 7seconds after the gas coming out, then tighten the flare nut again. Make sure the pressure display in the pressure indicator is a little higher than the atmosphere pressure.
- 7) Remove the charge hose from the Lo pressure charge hose.
- 8) Fully open the Hi and Lo packed valve.
- 9) Securely tighten the cap of the packed valve.

Gas leak check

Soap water method

Apply soap water or a liquid neutral detergent on the indoor unit connections or outdoor unit connections by a soft brush to check for leakage of the connecting points of the piping. If bubbles come out, the pipes have leakage.

PART6. Operation Description

1. Abbreviation

- T1: Indoor room temperature
- T2: Coil temperature of evaporator
- T3: Coil temperature of condenser
- T4: Outdoor ambient temperature
- T5: Compressor discharge temperature

2. Main Protection

2.1 Three Minutes Delay at restart for compressor

1 minute delay for the 1st time start-up and 3 minutes delay for others.

2.2 Temperature protection of compressor top

The unit will stop working when the compressor top temperature protector cut off, and will restart after the compressor top temperature protector restart.

2.3 Temperature protection of compressor discharge

When the compressor discharge temperature is getting higher, the running frequency will be limited as below rules:

---Compressor discharge temperature $T5 > 115^{\circ}\text{C}$ for 5s, compressor stops.

--- $108 < T5 < 115^{\circ}\text{C}$, decrease the frequency to the lower level every 3 minutes.

--- $90 < T5 < 105^{\circ}\text{C}$, keep running at the current frequency.

---- $T5 < 90^{\circ}\text{C}$, no limit for frequency.

2.4 Fan Speed is out of control

When Indoor Fan Speed keeps too low (300RPM) for certain time, the unit will stop and the LED will display the failure

2.5 Inverter module Protection

The Inverter module has a protection function about current, voltage and temperature. If these protections happen, the corresponding code will display on indoor unit and the unit will stop working.

2.6 Indoor fan delayed open function

When the unit starts up, the louver will be active immediately and the indoor fan will open 10s later.

If the unit runs in heating mode, the indoor fan will be also controlled by anti-cold wind function.

2.7 Compressor preheating functions

Preheating permitting condition:

If $T4$ (outdoor ambient temperature) $<3^{\circ}\text{C}$ and the machine connects to power supply newly or if $T4<3^{\circ}\text{C}$ and compressor has stopped for over 3 hours, the compressor heating cable will work.

Preheating mode:

A weak current flow through the coil of compressor from the wiring terminal of the compressor, then the compressor is heated without operation.

Preheating release condition:

If $T4>5^{\circ}\text{C}$ or the compressor starts running, the preheating function will stop.


2.8 Zero crossing detection error protection

If AC detects time interval is not correct for continuous 240s, the unit will stop and the LED will display the failure. The correct zero crossing signal time interval should be between 6-13ms.

3 Operation Modes and Functions

3.1 Fan mode


- (1) Outdoor fan and compressor stop.
- (2) Temperature setting function is disabled, and no setting temperature is displayed.
- (3) Indoor fan can be set to high/med/low/auto.
- (4) The louver operates same as in cooling mode.
- (5) Auto fan:




3.2 Cooling Mode

3.2.1 Compressor running rules

The maximum operation frequency of compressor after starting submits to following rule.



If users switch on AC by remote controller, the compressor will run at the Fmax frequency for 7 minutes according to the outdoor ambient temperature. During the 7 minutes, the frequency limitation is active. 7 minutes later, the compressor running frequency will be controlled as below:



While

Temperature	A	B	C	D	E	F	G
Frequency	F8	F8	F7	F6	F5	F3	F1

Note:

When $T1-Ts$ keeps in the same temperature zone for 3 minutes, the compressor will run as the below rules:


A~E: Increase the frequency to the higher level until to F8.

F: Keep the current frequency.

G: Decrease the frequency to the lower level until to F1.

H: Run at F1 for 1h.(if $T_1 - T_s < -2^\circ\text{C}$, the compressor will stop)

Meanwhile, the compressor running frequency is limited by the current.



Off: Compressor stops.

Decrease: Decrease the running frequency to the lower level.


Hold: Keep the current frequency.

Resume: No limitation for frequency.

Note:

When AC is in "hold" zone for 3 minutes, the compressor frequency will rise to the higher level.(frequency will increase twice at most)


3.2.2 Outdoor fan running rules



3.2.3 Indoor fan running rules

In cooling mode, indoor fan runs all the time and the speed can be selected as high, medium, low and auto.

Auto fan in cooling mode acts as follow:



3.2.4 Condenser temperature protection

--- $55^{\circ}\text{C} < T3 < 60^{\circ}\text{C}$, the compressor frequency will decrease to the lower level until to F1 and then runs at F1. If $T3 < 54^{\circ}\text{C}$, the compressor will keep running at the current frequency.

--- $T3 < 52^{\circ}\text{C}$, the compressor will not limit the frequency and resume to the former frequency.

--- $T3 > 60^{\circ}\text{C}$ for 5 seconds, the compressor will stop until $T3 < 52^{\circ}\text{C}$.

3.2.5 Evaporator temperature protection

--- $T2 < 0^{\circ}\text{C}$, the compressor will stop and restart when $T2 \geq 5^{\circ}\text{C}$.

--- $0^{\circ}\text{C} \leq T2 < 4^{\circ}\text{C}$, the compressor frequency will be limited and decreased to the lower level


--- $4^{\circ}\text{C} \leq T2 \leq 7^{\circ}\text{C}$, the compressor will keep the current frequency.

--- $T2 > 7^{\circ}\text{C}$, the compressor frequency will not be limited.

3.3 Heating Mode


3.3.1 Compressor running rules

The maximum operation frequency of the compressor after starting submits to the following rule.



If users switch on AC by remote controller, the compressor will run at the Fmax frequency for 7 minutes according to outdoor ambient temperature. During the 7 minutes, the frequency limitation is active.

7 minutes later, the compressor running frequency will be controlled as below:



While

Temperature	A	B	C	D	E	F	G
Frequency	F10	F9	F8	F7	F5	F3	F1

$\Delta T=0^{\circ}\text{C}$ as default.

Note:

When $T_1 - T_s$ keeps in the same temperature zone for 3 minutes, the compressor will run as the below rules:


A~E: Increase the frequency to the higher level until to F10.

F: Keep the current frequency.

G: Decrease the frequency to the lower level until to F1.

H: Run at F1 for 1h.(if $T_1 - T_s - \Delta T > 6^{\circ}\text{C}$, the compressor will stop)

Meanwhile, the compressor running frequency is limited by the current.



Off: Compressor stops.

Decrease: Decrease the running frequency to the lower level.


Hold: Keep the current frequency.

Resume: No limitation for frequency.


Note:

When AC is in “hold” zone for 3 minutes, the compressor frequency will rise to the higher level. (The frequency will increase twice at most)

3.3.2 Outdoor fan running rules



3.3.3 Indoor fan running rules




If the compressor stops caused by the room temperature rising, the indoor fan will be forced to run 127 seconds with breeze. During this period, the anti-cold-wind is disabled.

If the machine runs in rating capacity test mode, the indoor fan will run with rating speed and the anti-cold-wind function is disabled.

Indoor fan speed can be set as high, medium, low or auto fan and the anti-cold-wind function is preferential.

Auto fan action in heating mode:



3.3.4 Defrosting mode

Condition of defrosting:

---- $T_4 > 0^\circ\text{C}$,

When the units are running, if the following two items are satisfied, the units start defrosting:

The units run with $T_3 < 3^\circ\text{C}$ for 40 minutes and T_3 keeps lower than $T_{CDI}^\circ\text{C}$ for more than 3 minutes.

The units run with $T_3 < 3^\circ\text{C}$ for 80 minutes and T_3 keeps lower than $T_{CDI} + 2^\circ\text{C}$ for more than 3 minutes.

While $TCDI = -6^{\circ}\text{C}$.

---- $T4 < 0^{\circ}\text{C}$,

If the 1st condition and 2nd condition items are satisfied, then the program judges if $T2$ has decreased more than 5°C . When $T2$ has decreased more than 5°C , enter the defrosting mode.

----No matter what value $T4$ is, if the machine runs with $T3 < 3^{\circ}\text{C}$ for more than 120 minutes and $T3$ keeps lower than $TCDI + 4^{\circ}\text{C}$ for more than 3 minutes, the machine will enter defrosting mode no matter if $T2$ drops more than 5°C or not.

Condition of ending defrosting:

If any one of the following items is satisfied, the defrosting will finish and the machine will turn to normal heating mode.


---- $T3$ rises to be higher than $TCDE1^{\circ}\text{C}$.

---- $T3$ keeps to be higher than $TCDE2^{\circ}\text{C}$ for 80 seconds.


----The machine has run for 10 minutes in defrosting mode.

While $TCDE1 = 15^{\circ}\text{C}$, $TCDE2 = 8^{\circ}\text{C}$ for 18k, 24k model. $TCDE1 = 12^{\circ}\text{C}$, $TCDE2 = 8^{\circ}\text{C}$ for other models.

Defrosting action:



or



3.3.5 Evaporator coil temperature protection

----T2> TEH2°C, the compressor running frequency decreases to the lower level and runs for 20s.

When the frequency decreases to F2 and the T2 is still over TEH2°C for 3 minutes, the compressor will stop.

----T2<48°C or T2 stays in 48°C~ TEH2°C for 6 minutes, the frequency will not be limited by T2.

----T2>60°C, the compressor will stop and restart when T2<48°C.

While TEH2=55°C for 24k model, TEH2=53°C for other models.

3.4 Auto-mode

This mode can be chosen with remote controller and the setting temperature can be changed between 17~30°C.

In auto mode, the machine will choose cooling, heating or fan-only mode according to ΔT ($\Delta T = T1 - Ts$).

$\Delta T = T1 - Ts$	Running mode
$\Delta T > 1^\circ C$	Cooling
$-1 < \Delta T \leq 1^\circ C$	Fan-only
$\Delta T \leq -1^\circ C$	Heating

Indoor fan will run at auto fan of the relevant mode.

The louver operates same as in relevant mode.


If the machine switches mode between heating and cooling, the compressor will keep stopping for 15 minutes and then choose mode according to T1-Ts.

If the setting temperature is modified, the machine will choose running function again.

3.5 Drying mode

3.5.1 Indoor fan speed is fixed at breeze and can't be changed. The louver angle is the same as in cooling mode.

3.5.2 Compressor running rules



3.5.3 Low indoor room temperature protection

In drying mode, if room temperature is lower than 10°C, the compressor will stop and not resume until room temperature exceeds 12°C.

3.5.4 Evaporator anti-freezing protection, condenser high temperature protection and outdoor unit frequency limit are active and the same as that in cooling mode.

3.5.5 The outdoor fan operates the same as in cooling mode.

3.6 Forced operation function

3.6.1 Enter forced operation function:

When the machine is off, pressing the touch button will carry the machine to forced auto mode. After this, if press the button once again within 5 seconds, the machine will turn into forced cooling mode.

In forced auto, forced cooling or any other operation mode, pressing touch button will turn off the machine.

3.6.2 In forced operation mode, all general protections and remote control are available.

3.6.3 Operation rules:

Forced cooling mode:

The compressor runs at F2 frequency and indoor fan runs as breeze. After running for 30 minutes, the machine will turn to auto mode as 24°C setting temperature.

Forced auto mode:

The action of forced auto mode is the same as normal auto mode with 24°C setting temperature.

3.7 Timer function

3.7.1 Timing range is 24 hours.

3.7.2 Timer on. The machine will turn on automatically when reaching the setting time.

3.7.3 Timer off. The machine will turn off automatically when reaching the setting time.

3.7.4 Timer on/off. The machine will turn on automatically when reaching the setting “on” time, and then turn off automatically when reaching the setting “off” time.

3.7.5 Timer off/on. The machine will turn off automatically when reaching the setting “off” time, and then turn on automatically when reaching the setting “on” time.

3.7.6 The timer function will not change the AC current operation mode. Suppose AC is off now, it will not start up firstly after setting the “timer off” function. And when reaching the setting time, the timer LED will be off and the AC running mode has not been changed.

3.7.7 The setting time is relative time.

3.8 Sleep function mode

3.8.1 Operation time in sleep mode is 7 hours. After 7 hours the AC quits this mode and turns off.

3.8.2. Operation process in sleep mode is as follow:

When cooling, the setting temperature rises 1°C (be lower than 30°C) every one hour, 2 hours later the setting temperature stops rising and indoor fan is fixed as low speed.

When heating, the setting temperature decreases 1°C (be higher than 17°C) every one hour, 2 hours later the setting temperature stops rising and indoor fan is fixed as low speed. (Anti-cold wind function has the priority)

3.2 Timer setting is available

3.3 When user uses timer off function in sleep mode (or sleep function in timer off mode), if the timing is less than 7 hours, sleep function will be cancelled when reaching the setting time. If the timing is more than 7 hours, the machine will not stop until reaches the setting time in sleep mode.

3.9 Auto-Restart function

The indoor unit is equipped with auto-restart function, which is carried out through an auto-restart module. In case of a sudden power failure, the module memorizes the setting conditions before the power failure. The unit will resume the previous operation setting (not including swing function) automatically after 3 minutes when power returns.

If the memorization condition is forced cooling mode, the unit will run in cooling mode for 30 minutes and turn to auto mode as 24°C setting temperature

If AC is off before power off and AC is required to start up now, the compressor will have 1 minute delay when power on. Other conditions, the compressor will have 3 minutes delay when restarts.

3.10 Ionizer function (optional)

The indoor unit is equipped with Ionizer, which is controlled by the CLEAN AIR button on the remote controller. When the unit is turned on, press the CLEAN AIR button to activate the function. Press it again to stop the function. During the time when Ionizer is controlled by remote controller, Ionizer will be turned off automatically if indoor fan stops running due to malfunctions or anti-cold-wind. When indoor fan restarts after malfunctions being eliminated and anti-cold-wind being released, Ionizer will be available again.

3.11 8°C Heating(optional)

In heating operation, the preset temperature of the air conditioner can be as lower as 8°C, which keeps the room temperature steady at 8°C and prevents household things freezing when the house is unoccupied for a long time in severe cold weather.

PART7. Trouble Shooting


1. Indoor Unit Error Display

Display	LED STATUS
E0	EEPROM parameter error
E1	Indoor unit and outdoor unit communication protection
E2	Zero-crossing signal error
E3	Indoor fan speed has been out of control
E5	Open or short circuit of outdoor temperature sensor or outdoor unit EEPROM parameter error
E6	Open or short circuit of room or evaporator coil temperature sensor
E7	Outdoor fan speed has been out of control
P0	IBM malfunction or IGBT over-strong current protection
P1	Over voltage or too low voltage protection
P2	Temperature protection of compressor top.
P4	Inverter compressor drive error


Note: E4 & P3: Reserved function.

2. Diagnosis and Solution


2.1 EEPROM parameter error diagnosis and solution




2.2 Indoor unit and outdoor unit communication protection error diagnosis and solution




2.3 Fan speed has been out of control diagnosis




2.4 Open or short circuit of temperature sensor diagnosis and solution




2.5 IGBT over-strong current protection diagnosis and solution




2.6 Over voltage or too low voltage protection diagnosis and solution



2.7 High temperature protection of compressor top diagnosis and solution



2.8 Inverter compressor drive error diagnosis and solution



2.9 Zero crossing detection error


This is alarm signal when the main chip can't detect over-zero signal. When such failure occurs, the main control board must have fault.

3. Key parts checking

3.1 Compressor checking

Model: DA108X1C-20FZ3


Measure the resistance value of each winding by using the multi-meter.



Position	Resistance Value
Blue - Red	0.71Ω
Blue - Black	(20°C)
Red - Blue	

Model: DA130S1C-20FZ


Measure the resistance value of each winding by using the multi-meter.



Position	Resistance Value
Blue - Red	0.95Ω
Blue - Black	(20°C)
Red - Blue	

Model: DA150S1C-20FZ


Measure the resistance value of each winding by using the multi-meter.



Position	Resistance Value
Blue - Red	0.95Ω
Blue - Black	(20°C)
Red - Blue	

Model: DA250S2C-30MT

Measure the resistance value of each winding by using the multi-meter.




Position	Resistance Value
Blue - Red	0.55Ω
Blue - Black	(20°C)
Red - Blue	

3.2 Outdoor Fan Motor

Model: YDK24-6G


Measure the resistance value of each winding by using the multi-meter.



Position	Resistance Value
Black - Red	372Ω (20°C)
Blue - Red	249Ω (20°C)
Yellow - Blue	132Ω (20°C)

Model: YDK50-6C


Measure the resistance value of each winding by using the multi-meter.



Position	Resistance Value
Black - Red	114Ω (20°C)
Blue - Red	188Ω (20°C)
Yellow - Blue	172Ω (20°C)

Model: YDK55-6G


Measure the resistance value of each winding by using the multi-meter.



Position	Resistance Value
Black - Red	191Ω (20°C)
Red - Yellow	220Ω (20°C)

Model: YDK53-6N


Measure the resistance value of each winding by using the multi-meter.



Position	Resistance Value
Black - Red	87Ω (20°C)
Red - Yellow	162Ω (20°C)

Model: YDK100-6T

Measure the resistance value of each winding by using the multi-meter.




Position	Resistance Value
Black - Red	63Ω (20°C)
Red - Yellow	57Ω (20°C)

3.3 Indoor Fan Motor

Model: RPG20D


Measure the resistance value of each winding by using the multi-meter.



Position	Resistance Value
Black - Red	$400\Omega \pm 8\% (20^\circ\text{C})$
White - Black	$383\Omega \pm 8\% (20^\circ\text{C})$

Model: RPG28D


Measure the resistance value of each winding by using the multi-meter.



Position	Resistance Value
Black - Red	$260\Omega \pm 8\% (20^\circ\text{C})$
White - Black	$385\Omega \pm 8\% (20^\circ\text{C})$


Model: YDK36-4C(A)

Measure the resistance value of each winding by using the multi-meter.



Position	Resistance Value
White - Red	$272\Omega \pm 8\% (20^\circ\text{C})$
Brown- Black	$94\Omega \pm 8\% (20^\circ\text{C})$

Model: YDK50-4C




Position	Resistance Value
White - Red	$204\Omega \pm 8\% (20^\circ\text{C})$
Brown- Black	$95\Omega \pm 8\% (20^\circ\text{C})$

3.4 Step Motor


Model: MP2835, MP2423B

Measure the resistance value of each winding by using the multi-meter.



Model: MP2423

Measure the resistance value of each winding by using the multi-meter.



3.5 Temperature Sensors.

- Room temp.(T1) sensor,
- Indoor coil temp.(T2) sensor,
- Outdoor coil temp.(T3) sensor,
- Outdoor ambient temp.(T4) sensor,
- Compressor exhaust temp.(Te) sensor.

Measure the resistance value of each winding by using the multi-meter.


Some frequently-used R-T data for T1, T2, T3 and T4 sensor:

Temperature (°C)	5	10	15	20	25	30	40	50	60
Resistance Value (KΩ)	26.9	20.7	16.1	12.6	10	8	5.2	3.5	2.4

Some frequently-used R-T data for Te sensor:

Temperature (°C)	5	15	25	35	60	70	80	90	100
Resistance Value (KΩ)	141.6	88	56.1	36.6	13.8	9.7	6.9	5	3.7

KΩ



PART7, 13

8. Capacity table

42/38LUVH025N-1

SUMMER		OUTDOOR TEMPERATURE DRY					
Indoor Conditions		25°C	30°C	35°C	40°C	45°C	50°C
21°C D 15°C W	Total capacity W	2477	2356	2192	2013	1848	1724
	Sensitive capacity W	1751	1698	1624	1541	1462	1399
	Input W.	580	630	680	729	779	829
24°C D 17°C W	Total capacity W	2656	2537	2394	2241	2094	1968
	Sensitive capacity W	1857	1802	1737	1674	1625	1604
	Input W.	581	635	689	742	796	850
27°C D 19°C W	Total capacity W	2842	2789	2639	2434	2215	2024
	Sensitive capacity W	2012	1970	1895	1804	1712	1633
	Input W.	592	648	703	758	813	869
32°C D 23°C W	Total capacity W	2895	2942	2900	2800	2669	2537
	Sensitive capacity W	1907	1930	1914	1882	1859	1868
	Input W.	586	651	716	781	846	910

WINTER		OUTDOOR CONDITIONS					
Indoor Conditions		12°C D 11°C W	7°C D 6°C W	4°C D 3°C W	0°C D -1°C W	-4°C D -6°C W	-7°C D -8°C W
15°C	Capacity W	3435	3057	2703	1747	1461	1408
	Input W.	838	748	670	578	537	566
18°C	Capacity W	3235	2901	2615	1661	1533	1355
	Input W.	858	748	682	615	594	622
20°C	Capacity W	3218	2930	2592	1578	1418	1385
	Input W.	881	775	699	615	582	612
22°C	Capacity W	2992	2850	2473	1339	1433	1337
	Input W.	815	769	700	613	586	642

42/38LUVH035N-1

SUMMER		OUTDOOR TEMPERATURE DRY					
Indoor Conditions		25°C	30°C	35°C	40°C	45°C	50°C
21°C D 15°C W	Total capacity W	3303	3141	2922	2684	2464	2299
	Sensitive capacity W	2338	2268	2169	2058	1953	1869
	Input W.	771	837	903	969	1035	1101
24°C D 17°C W	Total capacity W	3541	3383	3192	2988	2793	2625
	Sensitive capacity W	2480	2408	2321	2236	2171	2142
	Input W.	772	843	915	986	1058	1129
27°C D 19°C W	Total capacity W	3789	3719	3519	3245	2953	2699
	Sensitive capacity W	2688	2631	2531	2410	2286	2182
	Input W.	787	860	934	1007	1080	1154
32°C D 23°C W	Total capacity W	3860	3922	3867	3733	3559	3383
	Sensitive capacity W	2547	2578	2557	2514	2483	2495
	Input W.	779	865	951	1037	1124	1210

WINTER		OUTDOOR CONDITIONS					
Indoor Conditions		12°C D 11°C W	7°C D 6°C W	4°C D 3°C W	0°C D -1°C W	-4°C D -6°C W	-7°C D -8°C W
15°C	Capacity W	4467	3975	3515	2272	1899	1830
	Input W.	1099	981	879	758	704	743
18°C	Capacity W	4207	3772	3401	2160	1994	1761
	Input W.	1125	981	894	807	779	816
20°C	Capacity W	4184	3810	3371	2051	1845	1801
	Input W.	1155	1016	917	807	764	803
22°C	Capacity W	3890	3706	3216	1742	1863	1739
	Input W.	1068	1009	918	804	769	842

42/38LUVH045N-1

SUMMER		OUTDOOR TEMPERATURE DRY					
Indoor Conditions		25°C	30°C	35°C	40°C	45°C	50°C
21°C D 15°C W	Total capacity W	4955	4711	4383	4026	3696	3448
	Sensitive capacity W	3509	3403	3254	3088	2930	2804
	Input W.	1276	1386	1495	1604	1713	1823
24°C D 17°C W	Total capacity W	5311	5074	4788	4483	4189	3937
	Sensitive capacity W	3722	3613	3482	3356	3258	3214
	Input W.	1278	1396	1515	1633	1752	1870
27°C D 19°C W	Total capacity W	5684	5578	5278	4868	4430	4048
	Sensitive capacity W	4033	3947	3798	3615	3430	3273
	Input W.	1303	1425	1546	1668	1789	1911
32°C D 23°C W	Total capacity W	5791	5883	5800	5600	5338	5074
	Sensitive capacity W	3822	3869	3836	3772	3725	3744
	Input W.	1290	1433	1575	1718	1860	2003

WINTER		OUTDOOR CONDITIONS					
Indoor Conditions		12°C D 11°C W	7°C D 6°C W	4°C D 3°C W	0°C D -1°C W	-4°C D -6°C W	-7°C D -8°C W
15°C	Capacity W	6531	5811	5138	3322	2777	2676
	Input W.	1741	1554	1393	1200	1115	1177
18°C	Capacity W	6150	5514	4971	3157	2915	2575
	Input W.	1782	1554	1417	1278	1234	1293
20°C	Capacity W	6117	5570	4928	2999	2697	2633
	Input W.	1830	1609	1452	1278	1210	1272
22°C	Capacity W	5687	5418	4702	2546	2723	2542
	Input W.	1693	1598	1455	1274	1218	1333

42/38LUVH055N-1

SUMMER		OUTDOOR TEMPERATURE DRY					
Indoor Conditions		25°C	30°C	35°C	40°C	45°C	50°C
21°C D 15°C W	Total capacity W	5771	5488	5105	4689	4305	4016
	Sensitive capacity W	4086	3963	3790	3596	3412	3265
	Input W.	1558	1692	1825	1958	2092	2225
24°C D 17°C W	Total capacity W	6187	5910	5577	5221	4879	4585
	Sensitive capacity W	4334	4207	4056	3908	3794	3743
	Input W.	1560	1705	1849	1994	2139	2283
27°C D 19°C W	Total capacity W	6621	6497	6148	5670	5160	4715
	Sensitive capacity W	4697	4597	4423	4211	3995	3812
	Input W.	1591	1739	1887	2036	2184	2333
32°C D 23°C W	Total capacity W	6745	6853	6756	6522	6218	5910
	Sensitive capacity W	4451	4506	4468	4393	4339	4360
	Input W.	1575	1749	1923	2097	2271	2445

WINTER		OUTDOOR CONDITIONS					
Indoor Conditions		12°C D 11°C W	7°C D 6°C W	4°C D 3°C W	0°C D -1°C W	-4°C D -6°C W	-7°C D -8°C W
15°C	Capacity W	7902	7031	6217	4020	3360	3238
	Input W.	2111	1884	1689	1455	1352	1427
18°C	Capacity W	7442	6673	6016	3820	3527	3116
	Input W.	2161	1884	1718	1549	1496	1568
20°C	Capacity W	7402	6740	5963	3629	3263	3186
	Input W.	2219	1952	1761	1549	1467	1542
22°C	Capacity W	6882	6556	5690	3081	3295	3076
	Input W.	2052	1937	1764	1545	1477	1617

42/38LUVH065N-1

SUMMER		OUTDOOR TEMPERATURE DRY					
Indoor Conditions		25°C	30°C	35°C	40°C	45°C	50°C
21°C D 15°C W	Total capacity W	6597	6273	5836	5361	4921	4590
	Sensitive capacity W	4671	4530	4332	4111	3900	3733
	Input W.	1699	1845	1990	2135	2281	2426
24°C D 17°C W	Total capacity W	7072	6756	6375	5968	5577	5242
	Sensitive capacity W	4955	4810	4636	4468	4337	4279
	Input W.	1701	1859	2016	2174	2332	2490
27°C D 19°C W	Total capacity W	7568	7427	7028	6481	5898	5390
	Sensitive capacity W	5370	5256	5057	4814	4567	4358
	Input W.	1734	1896	2058	2220	2382	2544
32°C D 23°C W	Total capacity W	7710	7833	7723	7455	7108	6756
	Sensitive capacity W	5088	5151	5107	5022	4960	4984
	Input W.	1717	1907	2097	2287	2477	2666

WINTER		OUTDOOR CONDITIONS						
Indoor Conditions		12°C D 11°C W	7°C D 6°C W	4°C D 3°C W	0°C D -1°C W	-4°C D -6°C W	-7°C D -8°C W	
15°C	Capacity W	8934	7949	7029	4544	3799	3661	
	Input W.	2470	2205	1976	1703	1583	1670	
18°C	Capacity W	8414	7544	6801	4319	3987	3523	
	Input W.	2528	2205	2010	1813	1750	1834	
20°C	Capacity W	8368	7620	6742	4103	3689	3602	
	Input W.	2596	2283	2061	1813	1716	1805	
22°C	Capacity W	7780	7412	6433	3484	3726	3478	
	Input W.	2401	2267	2064	1807	1728	1892	

42/38LUVH075N-1

SUMMER		OUTDOOR TEMPERATURE DRY					
Indoor Conditions		25°C	30°C	35°C	40°C	45°C	50°C
21°C D 15°C W	Total capacity W	8249	7843	7297	6703	6153	5740
	Sensitive capacity W	5840	5664	5417	5140	4877	4667
	Input W.	2055	2231	2407	2583	2759	2935
24°C D 17°C W	Total capacity W	8842	8447	7970	7463	6974	6554
	Sensitive capacity W	6195	6014	5797	5586	5423	5350
	Input W.	2058	2249	2439	2630	2821	3012
27°C D 19°C W	Total capacity W	9463	9286	8787	8104	7375	6740
	Sensitive capacity W	6714	6571	6322	6018	5710	5449
	Input W.	2098	2294	2490	2686	2881	3077
32°C D 23°C W	Total capacity W	9640	9794	9656	9322	8887	8447
	Sensitive capacity W	6362	6440	6386	6279	6201	6232
	Input W.	2078	2307	2537	2766	2996	3226

WINTER		OUTDOOR CONDITIONS					
Indoor Conditions		12°C D 11°C W	7°C D 6°C W	4°C D 3°C W	0°C D -1°C W	-4°C D -6°C W	-7°C D -8°C W
15°C	Capacity W	10306	9170	8108	5242	4382	4223
	Input W.	2851	2545	2281	1966	1827	1927
18°C	Capacity W	9705	8702	7845	4983	4599	4064
	Input W.	2918	2544	2320	2092	2020	2117
20°C	Capacity W	9653	8790	7777	4733	4255	4155
	Input W.	2997	2636	2378	2092	1981	2083
22°C	Capacity W	8975	8550	7420	4018	4298	4012
	Input W.	2772	2616	2383	2086	1995	2183